



QUICK GUIDE!


Cleaning your Promethean ActivPanel

ActivPanel Care

Proper care for your ActivPanel will ensure optimal use. The ActivPanel glass is specially formulated to provide the best possible interactive experience. In most cases, fingerprints and streaks are easily removed with a dry microfibre cloth. If you notice your ActivPanel needs more cleaning than this, please follow the steps below.

We recommend the screen cleaner linked below, which includes a microfibre cloth. The product can be ordered using the usual CENTROS process:

<https://cpc.farnell.com/it-dusters/sm-16/screen-mom-screen-cleaner-kit/dp/SA04048>

- 1 Use a microfibre cloth
- 2 Only use a verified screen cleaner
- 3 Spray liquid on to the cloth, **never** directly on to the ActivPanel
- 4 Wipe in a single direction


The diagram shows two sets of arrows. The first set consists of a downward-pointing arrow and an upward-pointing arrow. To the right of these is the word 'or'. The second set consists of a leftward-pointing arrow and a rightward-pointing arrow.
- 5 Ensure all moisture is removed from the ActivPanel after cleaning