

Calibration of Food Probe

Monthly Record

- The readings in **iced water** should be **-1°C to +1°C**, if outside this range the unit should be replaced or returned to the manufacturer to be recalibrated.
- The reading in **boiling water** should be **between 99°C and 101°C**, if outside this range the unit should be replaced or returned to the manufacturer to be recalibrated.

Date of First Probe Use		Date for probe renewal (2 years from initial use)	
-------------------------	--	---	--

DATE	BOILING WATER °C	CHECKED BY	ICE °C	CHECKED BY